



ReSound Key Hilfsmittel-Positionsnummern:

RIC-Hörsysteme:

ReSound Key 4 KE461-DRWC LP	13.20.22.9433
ReSound Key 4 KE461-DRWC MP	13.20.22.9434
ReSound Key 4 KE461-DRWC HP	13.20.22.9432
ReSound Key 4 KE461-DRWC UP	13.20.10.9125
ReSound Key 3 KE361-DRWC LP	13.20.22.9836
ReSound Key 3 KE361-DRWC MP	13.20.22.9837
ReSound Key 3 KE361-DRWC HP	13.20.22.9838
ReSound Key 3 KE361-DRWC UP	13.20.10.9281

ReSound Key 4 KE461-DRW LP	13.20.22.2316
ReSound Key 4 KE461-DRW MP	13.20.22.2317
ReSound Key 4 KE461-DRW HP	13.20.22.2315
ReSound Key 4 KE461-DRW UP	13.20.10.0842
ReSound Key 3 KE361-DRW LP	13.20.22.2322
ReSound Key 3 KE361-DRW MP	13.20.22.2323
ReSound Key 3 KE361-DRW HP	13.20.22.2321
ReSound Key 3 KE361-DRW UP	13.20.10.0844
ReSound Key 2 KE261-DRW LP	13.20.22.2310
ReSound Key 2 KE261-DRW MP	13.20.22.2311
ReSound Key 2 KE261-DRW HP	13.20.22.2309
ReSound Key 2 KE261-DRW UP	13.20.10.0840

ReSound Key 4 KE462-DRW LP	13.20.22.2319
ReSound Key 4 KE462-DRW MP	13.20.22.2320
ReSound Key 4 KE462-DRW HP	13.20.22.2318
ReSound Key 4 KE462-DRW UP	13.20.10.0843
ReSound Key 3 KE362-DRW LP	13.20.22.2325
ReSound Key 3 KE362-DRW MP	13.20.22.2326
ReSound Key 3 KE362-DRW HP	13.20.22.2324
ReSound Key 3 KE362-DRW UP	13.20.10.0845
ReSound Key 2 KE262-DRW LP	13.20.22.2313
ReSound Key 2 KE262-DRW MP	13.20.22.2314
ReSound Key 2 KE262-DRW HP	13.20.22.2312
ReSound Key 2 KE262-DRW UP	13.20.10.0841

ReSound Key 4 KE461-DRWC MP TSG	13.20.14.8359
ReSound Key 3 KE361-DRWC MP TSG	13.20.14.8643
ReSound Key 4 KE461-DRW MP TSG	13.20.14.3413
ReSound Key 3 KE361-DRW MP TSG	13.20.14.3415
ReSound Key 2 KE261-DRW MP TSG	13.20.14.3411
ReSound Key 4 KE462-DRW MP TSG	13.20.14.3414
ReSound Key 3 KE362-DRW MP TSG	13.20.14.3416
ReSound Key 2 KE262-DRW MP TSG	13.20.14.3412

HdO-Hörsysteme:

ReSound Key 4 KE467-DW	13.20.22.2307
ReSound Key 4 KE477-DW	13.20.22.2308
ReSound Key 4 KE488-DWH	13.20.10.0836
ReSound Key 4 KE498-DW	13.20.10.0837
ReSound Key 3 KE367-DW	13.20.22.2305
ReSound Key 3 KE377-DW	13.20.22.2306
ReSound Key 3 KE388-DWH	13.20.10.0834
ReSound Key 3 KE398-DW	13.20.10.0835
ReSound Key 2 KE267-DW	13.20.22.2303
ReSound Key 2 KE277-DW	13.20.22.2304
ReSound Key 2 KE288-DWH	13.20.10.0832
ReSound Key 2 KE298-DW	13.20.10.0833

ReSound Key 4 KE477-DW TSG	13.20.14.3628
ReSound Key 3 KE377-DW TSG	13.20.14.3627
ReSound Key 2 KE277-DW TSG	13.20.14.3629

IdO-Hörsysteme:

ReSound Key 4 KE4CIC-W-LP	13.20.22.5512
ReSound Key 4 KE4CIC-W-MP	13.20.22.5513
ReSound Key 4 KE4CIC-W-HP	13.20.22.5511
ReSound Key 4 KE4ITC-DW-MP	13.20.22.5515
ReSound Key 4 KE4ITC-DW-HP	13.20.22.5514
ReSound Key 4 KE4ITC-DW-UP	13.20.22.5516
ReSound Key 4 KE4ITE-DW-MP	13.20.22.5518
ReSound Key 4 KE4ITE-DW-HP	13.20.22.5517
ReSound Key 4 KE4ITE-DW-UP	13.20.22.5519
ReSound Key 3 KE3CIC-W-LP	13.20.22.5527
ReSound Key 3 KE3CIC-W-MP	13.20.22.5528
ReSound Key 3 KE3CIC-W-HP	13.20.22.5526
ReSound Key 3 KE3ITC-DW-MP	13.20.22.5530
ReSound Key 3 KE3ITC-DW-HP	13.20.22.5529
ReSound Key 3 KE3ITC-DW-UP	13.20.22.5531
ReSound Key 3 KE3ITE-DW-MP	13.20.22.5533
ReSound Key 3 KE3ITE-DW-HP	13.20.22.5532
ReSound Key 3 KE3ITE-DW-UP	13.20.22.5534
ReSound Key 2 KE2ITC-DW-MP	13.20.22.5521
ReSound Key 2 KE2ITC-DW-HP	13.20.22.5520
ReSound Key 2 KE2ITC-DW-UP	13.20.22.5522
ReSound Key 2 KE2ITE-DW-MP	13.20.22.5524
ReSound Key 2 KE2ITE-DW-HP	13.20.22.5523
ReSound Key 2 KE2ITE-DW-UP	13.20.22.5525