

RECOMMISSIONING GUIDE



GUIDE FOR RECOMMISSIONING A COMMERCIAL REFRIGERATOR/ FREEZER OR HEATED CABINET AFTER A MOTHBALLING PERIOD



1

CHECK CONDENSER COIL

If coils need cleaning, lift the louver assembly and clean the condenser coil to remove any accumulated debris (refrigerators and freezers only).



2

CLEAN EXTERIOR/INTERIOR SURFACES

Thoroughly clean all exterior and interior surfaces including shelving/trayslides.
WARNING: DO NOT use chlorine-based cleaners on the unit (outside of the EZ-Clean gaskets).



3

CHECK THE GASKETS

Open the door(s) and inspect the gasket(s) for proper condition and fit. Look for gaps and normal wear/tear. Clean and/or replace as necessary.



4

INSPECT THE DOORS

If unit doors do not close/seal properly, adjust the hinges and/or level cabinet.



5

CAREFULLY RESTORE POWER

Check the condition of plugs, cords, and outlets to ensure safety before turning the unit on.

- Once power has been restored, check that the exterior temperature display is working.
- Review alarm codes if alerted by display (Spec Line Smart Control).



6

ENSURE PROPER OPERATING TEMPERATURE

Allow cabinet to reach proper temperature before placing product inside:

- Refrigerator: 40°F or below.
- Freezer: 0°F or below.
- Heated cabinet: 140°F or above.

For questions, please contact Traulsen's Service department at 1-800-825-8220.